



## INSTRUCTIONS AND PARTS LIST FOR Models 33-493 Electric Tire Press

### II. OPERATION AND CONTROL

#### B. HOIST

- 2. CAUTION! Place the hoist crank on the lift drum shaft. The table is raised to the desired height by turning the crank after removing the table pins. Check to make sure the hoist cable is tracking correctly. Run the table channels from top to bottom. The cable should be on each of the two upper pulleys and should track back and forth on the cable drum. Always place table pins under the table channels when servicing or tracking the cable. If a tracking problem exists, contact the Dake factory for instructions. Be sure all table pins are fully inserted in place before applying pressure. Always remove or release pressure on the cable before pressure is applied.**

724 Robbins Road  
Grand Haven, MI 49417

Phone (616) 842-7110 · (800) 937-3253

Fax (616) 842-0859 (800) 846-3253

Web: [www.dakecorp.com](http://www.dakecorp.com)

E-Mail: [customerservice@dakecorp.com](mailto:customerservice@dakecorp.com)



## NO. 33-493 ELECTRIC POWERED HYDRAULIC TIRE PRESS

### I. SETTING UP PRESS FOR OPERATION

This press was shipped set-up ready for operation. Have an electrician connect the starter (Item 98) to a power line. The pump can rotate in either direction.

### II. OPERATION AND CONTROL

#### A. RAM MOVEMENT

To raise the ram, turn the release valve handle (Item 81) clockwise so that the release valve (Item 74) is closed. Then press the "raise" button (Item 97) to raise the ram. The ram will raise as long as the operator presses the "raise" button. Ram movement can be stopped at any time by releasing the "raise" button.

After the work has been contacted the press will build pressure. The press will continue to build pressure as the ram advances until the press reaches its maximum tonnage. At this point the relief valve (Item 69) will open allowing oil to return back to the reservoir.

When the ram reaches its maximum stroke of twelve (12) inches the guide angle (Item 101) will contact the stroke limit switch arm (Item 100) tripping the stroke limit switch (Item 99). This opens the electrical circuit to the motor stopping it and preventing the ram from moving any further.

To release pressure and lower the ram, turn the release valve handle (Item 81) counterclockwise to open the release valve (Item 74). This permits the oil to return to the reservoir and the ram to lower.

#### B. HOIST

The hoist hand crank (Item 17) is provided to raise or lower the upper platen (Item 15) to the proper height for work. To change the vertical position of the upper platen sufficient tension must first be applied to the hoisting cable (Item 32) to permit removal of the table pins (Item 13). The upper platen may then be raised or lowered to the desired position. Then all of the table pins must be inserted.

**NOTE: Be sure all table pins are in place before applying any pressure. Also slacken the cable. It is advisable to lower the upper platen one or two holes rather than run the ram and lower platen to the end of its stroke.**

### III. MAINTENANCE

#### A. IF OIL LEAKS UP AROUND PISTON -

##### 1. Oil above piston leather:

If the rated stroke of the press is exceeded repeatedly by running the piston so as to uncover the by-

pass hole in the side of the cylinder, the small amount of oil which drains back from the bypass line will collect above the piston leather. Eventually enough may accumulate so that when the piston is brought to the top of its stroke, oil is forced out between the piston guide and the piston.

This can be remedied by disconnecting the bypass tube line (Item 95) from the cylinder. Then raising the piston slowly to about 2½" less than its rated stroke allowing the oil above the piston cap to overflow out the bypass hole into a clean can. Replace the tube line. The oil can be put back into the reservoir by removing the fill plug on the top of the reservoir.

#### B. IF PRESS DOES NOT HOLD PRESSURE -

##### 1. Loose tube connections:

Check all connections and tighten any loose tube nuts.

##### 2. Dirt under release valve ball (Item 77):

To correct this condition, remove the release valve rod, packing nut, packing, and ball. Clean out the valve seat. Reseat the valve ball using a brass rod as a drift and tapping lightly. Reassemble the valve.

If this occurs frequently, the oil should be drained from the reservoir. Then flush the reservoir to remove dirt. Refill the reservoir using Mobil D.T.E. 26 or its equivalent hydraulic oil. The oil must be filtered carefully to remove any foreign substances. Remove 3/4" pipe plug (Item 48) and 1/8" pipe plug on the side of the reservoir. Fill with oil until oil reaches the 1/8" pipe tapped hole (7 gallons). Then replace both plugs.

**NOTE: Before filling the reservoir with oil check to see if ram is all the way down. Otherwise over filling could occur.**


##### 3. Worn cup leather:

If neither of the previous conditions seems to have been the cause of the press not holding pressure, the trouble may be that the piston leather is worn out or damaged. To inspect the leather, it is best to first remove the lower platen (Item 34). Next remove cap screws which bolt the piston guide to the cylinder flange. Piston and piston guide may now be lifted out of the cylinder and inverted. The leather can now be inspected and replaced if necessary. Reassemble the press being careful not to damage the lip of the leather cup as it enters the cylinder.

#### C. IF PRESS DOES NOT DEVELOP RATED TONNAGE -


##### 1. Dirt under release valve ball:

Refer to Section B2 above.




SECTION A


VALVE NO. 710557



ANCHOR BOLT LOCATION



SECTION A



SECTION A

**ALL PARTS PRICES INCREASED 10%  
EFFECTIVE JANUARY 1, 1987**

5131 - 52478 3 ea

ITEM NO.	PART NAME	NO. REQ'D	ITEM NO.	PART NAME	NO. REQ'D
1	Frame	1	48	3/4" Pipe Plug	1
2	Base Angles	2	49	1/4" Pipe Plug	1
3	5/8"-11 x 1-3/4" Hex Cap Screws	4	50	1/8" Pipe Plug	1
4	5/8" Lockwashers	4	51	3/8" Pipe Plug	1
5	5/8"-11 Hex Nuts	4	52	Breather Filter	1
6	Stop Blocks	4	46054	Oil (7 Gallons Required)	1
7	1/2"-13 x 1-1/4" Hex Cap Screws	8	43647	1/2" Lockwashers	6
8	1/2" Lockwashers	10	53	1/2" x 3/4" Hex Cap Screws	6
9	"Duke" Name Plate	1	54	Pump & Motor Base	1
10	No. 6-32 x 1/4" Self-Tapping Screw	4	55	Washer - Neoprene	4
11	Model No. Plate	1	43645	3/8" Lockwasher	4
12	No. 2 x 3/16" Drive Screws	2	56	3/8" x 1-1/4" Hex Cap Screws	4
13	Head Channels	2	57	Motor	1
14	Table Spacers	4	58	5/16"-18 x 3/4" Hex Cap Screws	4
15	3/4" Lockwashers	12	59	5/16" Lockwashers	4
16	3/4"-10 Hex Nuts	8	60	Pump Support	1
17	Table Pins	6	61	5/16"-18 x 1" Hex Cap Screws	4
18	3/8" x 2-1/2" Groov-Pins	6	62	5/16" Lockwashers	4
19	Upper Platen	1	63	Coupling	1
20	3/4"-10 x 2" Hex Cap Screws	4	64	Pump	1
21	Crank Assembly	1	65	1/2"-13 x 1" Soc. Hd. Cap Screws	4
22	Hoist Frame	1	66	1/2" Lockwashers	4
23	Cable Drum	1	67	Coupling Guard	1
24	Drum Shaft	1	68	#10-24 x 3/8" Round Head Screw	4
25	Drum Shaft Key	1	69	1/4" Pipe Plug	1
26	Worm Gear	1	70	3/4" x 3/4" FF-S Parker Pipe Nipple	1
27	Nat'l. Retaining Ring No. XSO-247	1	71	Connector Block	1
28	Worm Shaft	1	72	3/4" x 2-1/2" Pipe Nipple - Extra Strong	1
29	Worm Key	1	73	Relief Valve - (Set at 6000 psi)	1
30	Nat'l. Retaining Ring No. XSO-239	2	74	Intake Line (Reservoir - Dake Pump)	1
31	Hoist Assembly (Items 17 thru 27)	2	75	Hex Reducer 3/4"-3/8" - (In Reservoir) Steel	1
32	1/2"-13 x 1-1/2" Hex Cap Screws	2	76	1/2" Tube Elbow (In Pump)	1
33	Cable Pulley	2	77	Tube Assembly (Dake Pump - Relief Valve)	1
34	Cable Pulley Shaft	1	78	1/2" Tube Elbow	2
35	Cable Pulley Shaft	2	79	1/2" Tube Tee	1
36	Nat'l. Retaining Ring No. XSO-230	6	80	Release Valve "Section A"	1
37	Cable Clamps - 1/4"	1	81	Ball Retainer	1
38	Lower Platen	4	82	Ball Valve - 3/4" Dia.	1
39	3/4" x 3-1/4" 12 Pt. Cap Screws	4	83	Valve Rod	1
40	Decal "Warning - End of Stroke"	1	84	Valve Rod Packing (7 Req'd.)	1 set
41	Cylinder	1	85	Packing Nut	1
42	1/8" Pipe Plug	2	86	Handle	1
43	Piston	1	87	Washer	1
44	1/4" Pipe Plug	1	88	Valve Handle Bolt	1
45	Piston Guide	1	89	1/2" Pipe Plug	1
46	1/2"-13 x 4" Hex Cap Screws	6	90	Release Valve Spacer	1
47	1/2"-13 x 4-1/2" Hex Cap Screws	4	91	3/8"-16 x 2-1/4" Hex Cap Screws	2
48	1/2"-13 Hex Nuts	10	92	3/8" Lockwashers	2
49	1/2" Lockwashers	10	93	Stop-Release Valve Rod	1
50	Piston Cap	1	94	Gauge - 150 Ton	1
51	Piston Leather & Heel Washer	1	95	Pulsation Damper	1
52	Supporting Ring	1	96	1/2" x 1-1/2" Pipe Nipple - Extra Strong	1
53	3/8-16 x 1-3/4" Hex Cap Screws	8	97	1/2" Tube Elbow	1
54	3/8" Lockwashers	8	98	Tube Assembly (Release Valve to Cylinder)	1
55	Oil Seal	1	99	7/8" Tube Elbow	1
56	Retainer	3	100	7/8" Straight Fittings	3
57	#10-24 x 1/2" Flat Head Machine Screws	3	101	Tube Assembly (Release Valve to Reservoir)	1
58	Wear Ring	1	102	Tube Assembly - By-Pass (Cylinder-Reservoir)	1
59	Wear Ring	2	103	3/8" Straight Fittings	2
60	Workhead Assembly (Items 36 thru 45)	1	104	Hex Reducer 3/8"-1/4" (Steel)	1
61	Reservoir	1	105	1/4" x 1-1/2" Pipe Nipple - Extra Strong	1
62			106	1/4" Pipe Elbow 300F	1

\* Price on Application C.A. Commercially Available All prices are subject to change without notice. Prices do not include freight or average charge.

ITEM NO.	PART NO.	PART NAME	NO. REQ'D
**	29699	Pushbutton Contact Block .....	1
**	29774	Pushbutton Name Plate "Raise" .....	1
97	29782	Pushbutton Black Mushroom .....	1
**	43643	1/4" Lockwasher .....	3
**	43301	1/4"-20 x 1/2" Hex Cap Screws .....	3
		— IF 230 VOLT —	
98	38408	A. B. Starter No. 709AAA-43 .....	1
**	29724	N-26 Heater .....	3
		— IF 230 VOLT —	
98	38409	A. B. Starter No. 709AAB-43 .....	1
**	29722	N-19 Heater .....	3
99	35941	Micro Limit Switch No. LSA1A .....	1
100	46743	Micro Limit Switch Arm No. LSZ52CC .....	1
101	61063	Guide Angle (One Right Hand and One Left Hand) ...	2
**	43645	3/8" Lockwasher .....	4
**	43326	3/8"-16 x 3/4" Hex Cap Screw .....	4
	706540	Repair Kit (Items 41, 43, 77 & 79) .....	

\* Price on Application  
 \*\* Not Illustrated  
 C.A. Commercially Available  
 Items in Repair Kit

**ALL PARTS PRICES INCREASED 10%  
 EFFECTIVE JANUARY 1, 1987**

**2. Worn cup leather:**  
 Refer to Section B3 above.

**3. Relief valve set low:**  
 The relief valve (Item 69) has been set at the factory to bypass oil back to the reservoir when the press reaches its rated capacity. If, however, the press does not develop its rated tonnage and the above two conditions have been checked, the relief valve may need readjusting. To do this first remove the 1/4" pipe plug (Item 65) in the connector block. Now the valve adjustment screw can be reached with a 7/32" allen wrench. To increase the setting, turn the adjustment screw clockwise. Be careful not to adjust the valve over its rated tonnage or maximum operating pressure of 6000 psi.

**NOTE: Do not exceed the maximum operating pressure of 6000 psi.**

**D. NO RAM MOVEMENT — (motor runs when "raise" button is pressed)**

**1. Release valve open:**  
 Be sure to have release valve firmly closed when using press.

**2. Insufficient oil:**  
 Check oil level in the reservoir with the ram down. Remove the 1/8" pipe plug on the side of the reservoir. The oil level should be up to this hole.

**3. Pump loses its prime:**  
 Make sure all pump intake connections are tight — not enough oil in the reservoir.



## **SAFEGUARDING THE POINT OF OPERATION**

### **ANSI B11.2 – Hydraulic Power Presses Safety Requirements for Construction, Care and Use**

It is important that Dake press users have a clear understanding of their responsibility involving the care and use of their Dake hydraulic press, including point-of-operation safe guards. Dake strongly recommends that Dake press users obtain a copy of the current American National Standard Institute (ANSI) B11.2 standard, for a more complete understanding of their responsibilities.

ANSI B11.2 states the following, relative to point of operation safeguarding:

“Normally, only the employer (press user) can determine the requirements of the press productions system components, including the dies and methods for feeding. There fore, the employer is ultimately responsible to designate and provide the point-of-operation safeguarding system”.

The standard also discusses additional responsibilities of the employer. Some of the key responsibilities are:

- The employer is responsible for the safety, use and care of the hydraulic power press production system.
- The employer is responsible to consider the sources of hazards for all tasks to be implemented on the hydraulic power press production system.
- The employer is required to eliminate or control identified hazards in the scope of their work activity.
- The employer is responsible for the training of personnel, caring for, inspecting, maintaining and operating hydraulic press production systems to ensure their competence.
- The employer is responsible to provide and ensure that point-of-operation safeguarding is used, checked, maintained and where applicable, adjusted on ever production operation performed on a press production system.

A complete and current copy of the ANSI B11.2 standard can be obtained by contacting the following:

American National Standards Institute  
1430 Broadway  
New York, NY 10018

AMT – The Association for Manufacturing Technology  
7901 Westpark Drive  
Mclean, VA 22102